SYNERGY 21

LED battery-powered floodlight (30W, 3600lm, IP54) User manual S21-MBA-30

Item number 249639

This manual describes the installation, operation, and safety of the portable LED battery-powered floodlight. Please keep it for the entire life of the product and include it if you pass it on to someone else.

Contents

- 1. Intended Use
- 2. Safety Instructions
- 3. Scope of Delivery
- 4. Technical Specifications
- 5. Assembly & Commissioning
- 6. Operation
- 7. Operating Instructions
- 8. Maintenance & Cleaning
- 9. Troubleshooting
- 10. Disposal & Recycling
- 11. EU Conformity
- 12. Warranty & Support
- 13. Packaging Data

1. Intended use

Portable LED floodlight for temporary lighting indoors and outdoors. Powered by an external battery (18V) without mains charging.

2. Safety instructions

- Turn off the device and remove the battery before working.
- Use only compatible 18V batteries.
- Do not operate in potentially explosive areas.
- Observe the temperature range: -10°C to +40°C.
- Do not open or modify the device.
- Use the USB output (5V/2A) only for external devices.

3. Content

- LED battery-operated floodlight
- Operating instructions
- Notice: Battery not included

SYNERGY 21

4. Technical data

Parameter	Value
Dimensions	198 × 143,6 × 270mm
Material	Die-cast aluminum + plastic
Surface	Powder coating
Shock resistance	IK08
Protection	IP54
Protection class	III
Temperature range	-10°C bis +40°C
Certificate	EMC
Light source	COB, 1 Piece
Rated power	30W
Tension	DC18V/DC14.4V
Luminous flux	3600lm
Color reproduction	Ra ≥ 80
Color temperature	6500K
Efficiency	120 lm/W
Life	3 years
USB-output	5V / 2A
Operating time	approximately 3 h

5. Assembly and commissioning

- Place the device on a stable surface.
- Insert the battery.
- Press the button and select the desired brightness.

6. Operation

Button toggles between 25%-50%-75%-100%-OFF. USB output for external devices.

7. Operating instructions

IP54: splash-proof, IK08: shock-resistant. Protection class III: low voltage only.

SYNERGY 21

8. Maintenance and cleaning

- Disconnect the device from the power supply.
- Clean with a soft cloth.
- Do not use aggressive cleaning agents.

9. Troubleshooting

Problem	Remedy
Light does not start	Check battery
Short term	Charge or replace battery

10. Disposal & Recycling

Do not dispose of in household waste. Observe WEEE regulations. Recycle batteries separately.

11. EU conformity

Complies with Directives 2014/35/EU, 2014/30/EU, and 2011/65/EU. See manufacturer for full declaration.

2. Warranty and Support

Warranty according to national law. Contact the manufacturer.

13. Packaging data

Innerbox: $27,6 \times 20,6 \times 20,3 \text{cm} / 1,81 \text{kg}$ Outside box: $63,8 \times 29,1 \times 42,6 \text{cm} / 6 \text{ Stk}$

Total weight: 10,9kg / 14,1kg



Maistraße 2 - 82110, Germering, Germany synergy21@allnet.de Tel.: 089 / 894 222 22

